



Use this template if cutting your own spacer for lockable IR boxes.

See page 10 of the Infrared Counter Instructions for context.

Instructions:

- Print on Letter paper (8.5" x 11")
- Don't scale or zoom when printing
- - (i.e. set scale/zoom to 100% and do not "fit to")
- Use 1/2" thick material (1/2" actual thickness required)
- Drill holes 3/32" for softwood and plywood
- Drill holes 1/8" for hardwood

